



2008 Scheduled Maintenance Intervals

Miles (in thousands)	5/25/45/65/85/105	15/55/95	35/75
Kilometres (in thousands)	8/40/70/100/130/160	25/85/145	55/115
Engine Oil – change oil and replace filter	●	●	●
Wiper Blades – check condition and replace if necessary	●	●	●
Wiper/Washer/Headlight Washer – check adjustment and function, add fluid if necessary	●	●	●
Tires and Spare – check for wear and damage, check pressure	●		
– check for wear and damage, check pressure and renewal date of tire set (where applicable)		●	●
Tires – rotate	● 5K only		
Service Reminder Display – reset	●	●	●
Brake System – check for damage, leaks, pad thickness, fluid level	●	●	●
Cooling System – check level, add if necessary		●	●
Exhaust System – check for damage, leaks		●	●
Engine On Board Diagnostics – check fault memory		● Except Audi Q7, TT, A5, S5, R8	● Except Audi Q7, TT, A5, S5, R8
Engine Compartment – check for leaks		●	●
Battery – check and replace if necessary		●	●
Dust and Pollen Filter – replace		●	●
Automatic Transmission and Final Drive – check for leaks		●	●
Manual Transmission and Final Drive – check for leaks		●	●
Haldex Clutch – change oil			● A3, TT only
Front Axle – check for excessive play, check dust seals on ball joints and tie rod ends		● Except Audi Q7, TT, A5, S5, R8	●
Lights – check all lights, check headlight adjustment		● A8, S8 only	● Except Audi Q7, TT, R8, A5, S5
Drive Shaft Boots – check		●	●
Doors – lubricate doors, check straps and hood latch		● A8, S8 only	●
Spark Plugs – replace at 35,000 miles or 3 years, whichever occurs first. Then, every 40,000 miles or 3 years, whichever occurs first.			● 35K only: A3 3.2L, TT 3.2L, A8 6.0L
– replace at 55,000 miles or 6 years, whichever occurs first. Then, every 60,000 miles or 6 years, whichever occurs first.		● 55K only: except A3 3.2L, TT 3.2L, A8 6.0L	
– replace at 75,000 miles			● 75K only: A3 3.2L, TT 3.2L, A8 6.0L
Continuously Variable Transmission (multitronic) – change ATF			●
Power Steering Fluid – check, add if necessary			●
Air Cleaner – clean housing, replace filter element		● 55K only: except RS 4, Audi Q7 4.2L, A8 6.0L	● 35K only: RS 4, A8 6.0L 75K only: RS 4, Audi Q7 4.2L, A8 6.0L
Ribbed V Belt and Tensioner – check condition and replace if necessary		● RS 4, R8 only	● RS 4, Audi Q7 3.6L, A8 6.0L, R8 only
Ribbed V Belt – replace			● 75K only: S4
– check condition and replace if necessary. Check tension of belt drive with manual tensioner and retension if necessary.			● 75K only: 2.0L, 3.2L, 4.2L FSI, 5.2L
Snow Screen for Air Cleaner – clean		● A4, A5, S5 and A6 only	● A4, A5, S5 and A6 only
Underbody – check for damage and leaks		●	●
Road Test – check braking, kick-down, steering, electrical, heating and ventilation systems, air conditioning, ASL Automatic Shift Lock and power accessories		●	●
Rear Lid Hinges – lubricate		● A8, S8 only	● A8, S8 only
Horn – check function		●	●
Brake Discs – check thickness			●
Lights – check all lights via instrument cluster. Check license plate light from the rear of the vehicle			● Audi Q7, TT, A5, S5, R8 only
Interior Lights – check all interior lights, glove box illumination, control lights and MMI (if applicable)			●
S Tronic – change oil and replace filter element			● A3, TT only

At 110K miles (175km) replace timing belt (2.0L engine only). Check condition of timing belt tensioning system, dampening pulleys, and idler pulleys and replace if necessary (2.0L engine only).

Brake Fluid – replace every 2 years regardless of mileage.

Cloth Top – check function and rollover protection every 2 years regardless of mileage (Audi A4 Cabriolet, S4 Cabriolet and RS 4 Cabriolet only).

Audi of America, Inc. believes the information and specifications to be correct at the time of printing. Specifications, maintenance intervals, standard features and options subject to change without notice.